




# Fuel and Emissions

## - DLC and MIL Circuits



\* = Non-SAE terminal number used in Service Manual.