


Connector Views

21. Airbag Inflator, Driver's or Passenger's

– Yellow



Driver's:

- Inside of steering wheel
- On cable reel assembly

1 Male – BLK
Female – RED
(Airbag control)

2 Male – BLK
Female – RED
(Airbag control)

Passenger's:

- Behind glove box
- On floor wire harness

1 Male – YEL or BLU
Female – RED
(Airbag control)

2 Male – GRN or BLU
Female – RED
(Airbag control)