




Connector Views

43. Heater Core Temperature Sensor

- Gray
- Behind center lower cover
- On dashboard wire harness A



- 1 Male – BLK
Female – LT GRN
(Circuit 331)
- 2 Male – BLK
Female – RED/WHT
(Heater core coolant temperature sensor output)