




Connector Views

84. Fuel Tank Pressure Sensor

- Right side of fuel tank
- On floor wire harness

'00-'05

- Gray
- On floor wire harness



- 1 YEL/BLU (Reference voltage (VCC2))
- 2 GRN/BLK (Circuit Z28)
- 3 LT GRN (Sensor output (PTANK))

'06

- Black
- On canister sub-harness



- 1 YEL/BLU (Reference voltage (VCC2))
- 2 LT GRN (Sensor output (PTANK))
- 3 GRN/BLK (Circuit Z28)