




# Connector Views

## 121. EGR Valve and EGR Valve Position Sensor

- Gray
- Middle of engine
- On engine wire harness



- 1 WHT/BLK (Sensor input (EGRP))
- 2 GRN/BLK (Sensor ground (SG2))
- 3 YEL/BLU (Reference voltage (VCC2))
- 4 PNK (Valve control (EGR))
- 5 —
- 6 BLK (G101)