




Connector Views

203. C108 (Junction Connector) (CVT)

- White
- Right side of floor
- On engine wire harness



- 1 BLK/YEL
(Fuse 4 – Under-dash)
- 2 —
- 3 BLK/YEL
(Fuse 4 – Under-dash)
- 4 BLK/YEL
(Fuse 4 – Under-dash)
- 5 BLK/YEL
(Fuse 4 – Under-dash)
- 6 BLK/YEL
(Fuse 4 – Under-dash)

7 —

- 8 —
- 9 '00-'04: WHT/BLU
(Fuse 18 – Under-dash)
- 10 '00-'04: WHT/BLU
(Fuse 18 – Under-dash)
- 11 '00-'04: WHT/BLU
(Fuse 18 – Under-dash)

- 12 GRN/BLK (Circuit M34)
- 13 GRN/BLK (Circuit M34)
- 14 GRN/BLK (Circuit M34)
- 15 GRN/BLK (Circuit M34)

16 —

- 17 RED/WHT (Circuit E91)
- 18 RED/WHT (Circuit E91)
- 19 RED/WHT (Circuit E91)
- 20 RED/BLK (Circuit E88)
- 21 RED/BLK (Circuit E88)
- 22 RED/BLK (Circuit E88)

Terminals grouped together are connected by the same bus bar.