

Connector to Harness Index

Dashboard Wire Harness A

Ref	Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
1	Fuel consumption display select switch	6-NAT	Left side of dash	Dashboard wire harness B (left branch) (see page 203-12)	CVT
2	Power window master switch	14-GRY	Left side of dash		
3	Power mirror switch	10-GRN	Left side of dash		
4	C404	24- LT BLU	Under left side of dash		
5	C405	14-GRY	Under left side of dash		
6	Gauge assembly connector A	30-GRN	Left side of dash		
7	Gauge assembly connector B	22-GRN	Left side of dash		
8	Gauge assembly connector C	10-GRN	Left side of dash		
9	Sunlight sensor	2-GRY	Top middle of dash		
10	Climate control unit/heater control panel connector A	12-GRY	Middle of dash		
11	Climate control unit/heater control panel connector B	22-GRN	Middle of dash	Dashboard wire harness B (right branch) (see page 203-14) Dashboard wire harness B (right branch) (see page 203-14) Floor wire harness (see page 203-18) Engine compartment wire harness (see page 203-10)	CVT
12	Hazard warning switch	10-GRY	Middle of dash		
13	In-car temperature sensor	2-GRY	Right side of steering column		
14	C410	10-GRY	Behind center lower cover		
15	C408	16- LT BLU	Behind center lower cover		
16	Heater core temperature sensor	2-GRY	Behind center lower cover		
17	C504	16-BLU	Behind center lower cover		
18	Mode control motor	7-GRN	Under middle of dash		
19	C531	16- LT BLU	Under left side of dash		
20	C571 (Junction Connector)	20-BLU	Left side of dash		



Connector to Harness Index

