
Connector Views

- Terminal Numbering System

The cavities (and wire terminals) in each connector are numbered starting from the upper left, looking at the male terminals from the <u>terminal</u> side (or looking at the female terminals from the <u>wire</u> side. Both views are in the same direction so the numbers are the same.) All actual cavities are numbered, even if they have no wire terminals in them.

NOTE: Data Link Connector (DLC) terminals are numbered according to SAE standard J1962, not the Honda standard. The numbers of the four end terminals are molded into the corners of the connector face.



The connector cavity number is listed next to each terminal on the circuit schematic. The cavity/terminal shown below is #6.

