

| | | |
|---|---------------------------|--------------------------------------|
| Last Modified: 12-04-2024 | 6.11:8.1.0 | Doc ID: RM10000002C0DS |
| Model Year Start: 2023 | Model: Prius Prime | Prod Date Range: [03/2023 -] |
| Title: PARK ASSIST / MONITORING: PANORAMIC VIEW MONITOR SYSTEM: DIAGNOSTIC TROUBLE CODE CHART; 2023 - 2024 MY Prius Prius Prime [03/2023 -] | | |

DIAGNOSTIC TROUBLE CODE CHART

Panoramic View Monitor System

| DTC NO. | DETECTION ITEM | DTC OUTPUT FROM | PRIORITY | LINK |
|---------|--|--|----------|----------------------|
| C161404 | Circumference Monitoring Camera Control Module System Internal Failure | Circumference Monitoring Camera Control Module | A | INFO |
| C161B04 | Rear Camera Control Module System Internal Failure | Circumference Monitoring Camera Control Module | A | INFO |
| C162011 | Rear Camera Circuit Short to Ground | Circumference Monitoring Camera Control Module | A | INFO |
| C162287 | Rear Camera Image Signal Missing Message | Circumference Monitoring Camera Control Module | A | INFO |
| C168011 | Front Camera Circuit Short to Ground | Circumference Monitoring Camera Control Module | A | INFO |
| C168187 | Front Camera Image Signal Missing Message | Circumference Monitoring Camera Control Module | A | INFO |
| C16891E | IR Floodlight Circuit Resistance Out of Range | Circumference Monitoring Camera Control Module | A | INFO |
| C168E87 | Side Camera (Left) Image Signal Missing Message | Circumference Monitoring Camera Control Module | A | INFO |
| C168F11 | Side Camera (Left) Circuit Short to Ground | Circumference Monitoring Camera Control Module | A | INFO |
| C169D87 | Side Camera (Right) Image Signal Missing Message | Circumference Monitoring Camera Control Module | A | INFO |
| C169E11 | Side Camera (Right) Circuit Short to Ground | Circumference Monitoring Camera Control Module | A | INFO |

| DTC NO. | DETECTION ITEM | DTC OUTPUT FROM | PRIORITY | LINK |
|---------|---|--|----------|----------------------|
| U012687 | Lost Communication with Steering Angle Sensor Module Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U012987 | Lost Communication with Brake System Control Module "A" Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U013187 | Lost Communication with Power Steering Control Module Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U014087 | Lost Communication with Body Control Module Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U015587 | Lost Communication with Instrument Panel Cluster (IPC) Control Module Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U016387 | Lost Communication with Navigation Control Module Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U019887 | Lost Communication with Telematic Control Module "A" Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U029387 | Lost Communication with Hybrid/EV Powertrain Control Module Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U111087 | Lost Communication with Clearance Sonar Module Missing Message | Circumference Monitoring Camera Control Module | B | INFO |
| U11B687 | Lost Communication with Intuitive Parking Assist Module (ch2) Missing Message | Circumference Monitoring Camera Control Module | A | INFO |

