

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028FBV
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: PARK ASSIST / MONITORING: REAR VIEW MONITOR SYSTEM: PRECAUTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

PRECAUTION

PRECAUTION FOR DISCONNECTING CABLE FROM NEGATIVE BATTERY TERMINAL

NOTICE:

After the ignition switch is turned off, there may be a waiting time before disconnecting the auxiliary negative (-) battery terminal.

Click here [INFO](#)

HINT:

When disconnecting and reconnecting the battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

POINTS TO NOTE WHEN SERVICING

(a) Pay attention to the following point when servicing.

- (1) A clear image may not be displayed if there is foreign matter such as water drops, snow or mud on the rear television camera lens. In such a case, wash the lens with a large amount of water and then wipe it with a soft wet cloth. Do not scrub the camera lens as scrubbing may scratch the camera lens and affect the quality of the image.

NOTES FOR REAR TELEVISION CAMERA ASSEMBLY

(a) Notes for the rear television camera assembly

- (1) The rear view monitor system may not function properly if subjected to a severe blow by any hard object.
- (2) The cover part of the camera is made of resin. If any organic solvent, degreaser, wax or glass coating contacts the cover, immediately wipe it off and wash the cover with water or cracks may develop.
- (3) Exposing the camera to a sudden temperature change may affect proper functioning of the camera.
- (4) A clear image may not be displayed if there is foreign matter such as water drops, snow or mud on the rear television camera lens. In such a case, wash the lens with a large amount of water and then wipe it with a soft wet cloth. Do not scrub the camera lens as scrubbing may scratch the camera lens and affect the quality of the image.
- (5) When washing the vehicle with a high-pressure washer, do not spray water on the rear television camera assembly or surrounding area. High-pressure water can damage the camera.

(b) Images may be unclear even in normal conditions if:

- (1) Electrical devices are used in the cabin (noise may occur in the image).
- (2) Accessories that generate radio waves have been installed (noise may occur in the image).
- (3) The outer mirror switch assembly is operated (noise may occur in the image).
- (4) The multi-display is cold (the image immediately after turning the ignition switch to ON may be blurred or darker than normal).
- (5) The camera lens is dirty with snow, mud, etc.
- (6) A strong beam of light, such as a sunbeam or headlight, hits the camera.
- (7) It is too dark around the camera (at night etc.).

- (8) The ambient temperature around the camera is either too high or too low.
- (9) The vehicle is tilted at a steep angle.
- (10) The rear television camera assembly lens is scratched.
- (11) The rear television camera assembly lens has drops of water on it or the humidity is high.
- (12) When the camera is used under fluorescent lights, sodium lights, mercury lights, etc., the lights and the illuminated area may appear to flicker.

