

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028P35
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: PARKING BRAKE: ELECTRIC PARKING BRAKE SYSTEM: DTC CHECK / CLEAR; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DTC CHECK / CLEAR

CHECK DTC AND FREEZE FRAME DATA

- (a) Turn the ignition switch off.
- (b) Connect the GTS to the DLC3.
- (c) Turn the ignition switch to ON.
- (d) Turn the GTS on.
- (e) Enter the following menus: Chassis / Brake/EPB / Trouble Codes.

Chassis > Brake/EPB > Trouble Codes

- (f) Check for DTCs.

Click here [INFO](#)

NOTICE:

The electric parking brake system outputs DTCs for the following system. When DTCs other than those in Diagnostic Trouble Code Chart for the electric parking brake system are output, refer to Diagnostic Trouble Code Chart for the relevant system.

SYSTEM	PROCEED TO
Electronically Controlled Brake System	INFO

- (g) Check the freeze frame data.
 - (1) If DTCs are output, check the freeze frame data and read the vehicle status when the DTC was stored.

HINT:

for Freeze Frame Data: Click here [INFO](#)

- (h) Clear the DTCs.

Chassis > Brake/EPB > Clear DTCs

HINT:

When DTCs are cleared, the freeze frame data will also be cleared.

