


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002B00J
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: M20A-FXS (EMISSION CONTROL): FUEL TANK PRESSURE SENSOR (for PHEV Model): INSTALLATION; 2023 - 2024 MY Prius Prime [03/2023 -]		

INSTALLATION

CAUTION / NOTICE / HINT

COMPONENTS (INSTALLATION)



	PROCEDURE	PART NAME CODE			
1	FUEL TANK PRESSURE SENSOR (VAPOR PRESSURE SENSOR)	89461	INFO	-	-
2	FUEL TANK SUB-ASSEMBLY	77100U	-	-	-


PROCEDURE

1. INSTALL FUEL TANK PRESSURE SENSOR (VAPOR PRESSURE SENSOR)

!

NOTICE:

- Check that there are no scratches or foreign matter around the connecting parts of the fuel tank pressure sensor (vapor pressure sensor) and fuel suction plate sub-assembly before performing this work.
- Check that the fuel suction plate sub-assembly is securely inserted to the end of the fuel tank pressure sensor (vapor pressure sensor).
- Check that the tube joint clip is on the collar of the fuel tank pressure sensor (vapor pressure sensor).
- After installing the tube joint clip, check that the fuel tank pressure sensor (vapor pressure sensor) cannot be pulled out.



*1	Tube Joint Clip	-	-
*a	O-ring	*b	Collar

(1) Push the fuel tank pressure sensor (vapor pressure sensor) onto the fuel suction plate sub-assembly, then install the tube joint clip.

2. INSTALL FUEL TANK SUB-ASSEMBLY

Click here [INFO](#)

