

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029UWE
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: M20A-FXS (EMISSION CONTROL): PCV VALVE: REMOVAL; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

REMOVAL

CAUTION / NOTICE / HINT

The necessary procedures (adjustment, calibration, initialization or registration) that must be performed after parts are removed and installed, or replaced during PCV valve (ventilation valve sub-assembly) removal/installation are shown below.

Necessary Procedures After Parts Removed/Installed/Replaced

REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURE	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED	LINK
<ul style="list-style-type: none"> Replacement of throttle body with motor assembly Cleaning the deposits from the throttle body with motor assembly Gas leaks from exhaust system is repaired 	Inspection After Repair	<ul style="list-style-type: none"> Poor idle, etc. Engine start function, etc. 	INFO


NOTICE:




This procedure includes the installation of small-head bolts. Refer to Small-Head Bolts of Basic Repair Hint to identify the small-head bolts.

Click here [INFO](#)

CAUTION / NOTICE / HINT

COMPONENTS (REMOVAL)




PROCEDURE		PART NAME CODE			
1	INTAKE MANIFOLD	17111	-	-	-
2	PCV VALVE (VENTILATION VALVE SUB-ASSEMBLY)	12204C	-	-	-

PROCEDURE

1. REMOVE INTAKE MANIFOLD

Click here [INFO](#)

2. REMOVE PCV VALVE (VENTILATION VALVE SUB-ASSEMBLY)



c

