


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM1000000029UW5
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: M20A-FXS (EMISSION CONTROL): PURGE VALVE: REMOVAL; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		




REMOVAL

CAUTION / NOTICE / HINT

COMPONENTS (REMOVAL)



	PROCEDURE	PART NAME CODE			
1	NO. 2 FUEL VAPOR FEED HOSE	23827A	-	-	-
2	FUEL VAPOR FEED HOSE ASSEMBLY	23820	-	-	-


	PROCEDURE	PART NAME CODE			
3	PURGE VALVE (PURGE VSV)	25860	-	-	-

NOTICE:


When removing the fuel vapor feed hose, hold the purge valve body securely in place by hand.

PROCEDURE

1. DISCONNECT NO. 2 FUEL VAPOR FEED HOSE



2. DISCONNECT FUEL VAPOR FEED HOSE ASSEMBLY



3. REMOVE PURGE VALVE (PURGE VSV)

