

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028W2J
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: M20A-FXS (ENGINE CONTROL): SFI SYSTEM: CHECK FOR INTERMITTENT PROBLEMS; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

CHECK FOR INTERMITTENT PROBLEMS

HINT:

Inspect the vehicle ECM using check mode. Intermittent problems are easier to detect with the GTS when the ECM is in check mode. In check mode, the ECM uses 1 trip detection logic, which is more sensitive to malfunctions than normal mode (default), which uses 2 trip detection logic.

1. Clear the DTCs.
2. Change the ECM from normal mode to check mode using the GTS.

Click here [INFO](#)

3. Perform a simulation test.

Click here [INFO](#)

4. Check and wiggle the harness(es), connector(s) and terminal(s).

Click here [INFO](#)

