Last Modified: 12-04-2024	6.11:8.1.0 Doc ID: RM1000000029A4V				
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]			
Title: HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for M20A-FXS): P1C8549; High Voltage Power					
Resource Internal Electronic Failure; 2023 - 2024 MY Prius Prius Prime [12/2022 -]					

DTC	P1C8549	High Voltage Power Resource Internal Electronic Failure	
-----	---------	---	--

DESCRIPTION

The battery ECU assembly monitors an internal operation of the hybrid vehicle control ECU. If it detects a malfunction, it will be output this DTC and performs fail-safe control.

DTC	DETECTION	DTC DETECTION	TROUBLE	MIL	WARNING	DTC	PRIORITY	NOTE
NO.	ITEM	CONDITION	AREA		INDICATE	OUTPUT FROM		
P1C8549	High Voltage Power Resource Internal Electronic Failure	An abnormal signal is detected by the battery ECU assembly (excessive discharging current). (1 trip detection logic)	Hybrid vehicle control ECU	Does not come on	lWarning:	HV Battery		SAE Code: P3004

CONFIRMATION DRIVING PATTERN

HINT:

After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

Click here NFO

- 1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- 2. Turn the ignition switch off and wait for 2 minutes or more.
- 3. Drive the vehicle for approximately 10 minutes according to the freeze frame data items "Vehicle Speed", "Accelerator Position" and "Hybrid/EV Battery Current".
- 4. Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
- 5. Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE, perform driving pattern again.

PROCEDURE

1. CHECK DTC OUTPUT (HV BATTERY, HYBRID CONTROL)

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

Powertrain > HV Battery > Trouble Codes Powertrain > Hybrid Control > Trouble Codes

RESULT	PROCEED TO	
"P1C8549" only is output.	А	
DTCs except "P1C8549" of hybrid battery system are output.	В	
DTCs except "P1C8549" of hybrid control system are output.	С	

Post-procedure1

(c) Turn the ignition switch off.









