

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000002B7B0
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: HYBRID / BATTERY CONTROL: CHARGE INDICATOR (for PHEV Model): INSPECTION; 2023 - 2024 MY Prius Prime [03/2023 -]		

INSPECTION


PROCEDURE

1. INSPECT EV CHARGER LID INDICATOR

(a) Inspect illumination

(1) Apply auxiliary battery voltage between the terminals of the indicator, and check the illumination condition of the EV charger lid indicator.

OK:



MEASUREMENT CONDITION	SPECIFIED CONDITION
Auxiliary Battery positive (+) → 1 (PIL) Auxiliary Battery negative (-) → 3 (GND)	Illuminates

If the result is not as specified, replace the EV charger lid indicator.

*a	Component without harness connected (EV Charger Lid Indicator)
----	--

