

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002A2HK
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: M20A-FXS (BATTERY / CHARGING): CHARGING SYSTEM: DIAGNOSIS SYSTEM; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DIAGNOSIS SYSTEM

DLC3 (Data Link Connector 3)

(a) Check the DLC3.

Click here [INFO](#)

AUXILIARY BATTERY VOLTAGE

Standard Voltage:

SWITCH CONDITION	SPECIFIED CONDITION
Ignition switch ON	11 to 14 V

If voltage is below 11 V, recharge or replace the auxiliary battery.

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the auxiliary negative (-) battery terminal.

Click here [INFO](#)

- When disconnecting and reconnecting the auxiliary battery.

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

