

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM1000000029XTJ
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: MAINTENANCE: GENERAL MAINTENANCE: BODY; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

BODY

TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

(a) If necessary, tighten the bolts and nuts on the chassis parts listed below.

- Front axle and suspension
- Drivetrain
- Rear axle and suspension
- Brake system
- Engine mounts
- Other chassis parts

(b) If necessary, tighten the bolts and nuts on the body parts listed below.

- Seat belt system
- Seats
- Doors and hood
- Body mounts
- Fuel tank
- Exhaust system
- Other body parts

CLEAN OR REPLACE AIR CONDITIONING FILTER

(a) Remove the air conditioning filter.

Click here [INFO](#)

(b) Visually inspect the surface of the air conditioning filter.

(c) If the air conditioning filter is contaminated with foreign matter, clean or replace it according to the maintenance schedule.

NOTICE:

Some filters are not able to be cleaned.

ROAD TEST

- Check the engine and chassis for abnormal noises.
- Check that the vehicle does not wander or pull to one side.
- Check that the brakes work properly and do not drag.
- Bed-in the parking brake pads.

BODY INSPECTION

- Check the body exterior for dents, scratches and rust.
- Check the underbody for rust and damage.

If necessary, replace any damaged parts or repair any damaged areas.

FINAL INSPECTION

- Check the operation of the body parts.
 - Hood

- Auxiliary catch operates properly.
- Hood locks securely when closed.

(2) Front and rear doors

- Door locks operate properly.
- Doors close properly.

(3) Back door

Door lock operates properly.

(4) Seats

- Seats adjust easily and lock securely in any position.
- Front seatbacks lock securely in any position.
- Fold-down rear seatbacks lock securely.

(5) Be sure to deliver a clean car. Make sure to check the following:

- Steering wheel
- Shift lever knob
- All switches and knobs
- Door handles
- Seats

