

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM1000000029XTH
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: MAINTENANCE: GENERAL MAINTENANCE: BRAKE; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

BRAKE


INSPECT BRAKE LINE PIPES AND HOSES

HINT:

Work in a well-lighted area. Turn the front wheels fully to the right or left before beginning the inspection.

(a) Using a mirror, check the entire circumference and length of the brake lines and hoses for:

- Damage
- Wear
- Deformation
- Cracks
- Kinks
- Corrosion
- Leaks
- Twists



(b) Check all the clamps for tightness and check the connections for leakage.

(c) Check that the hoses and lines are not near sharp edges, moving parts or the exhaust system.

(d) Check that the lines are installed properly and pass through the center of the grommets.

INSPECT BRAKE PEDAL

(a) Inspect the brake pedal.

Click here [INFO](#)

INSPECT PARKING BRAKE

(a) Inspect the parking brake.

INSPECT FRONT BRAKE

(a) Inspect the front brake pads and discs.

Click here [INFO](#)

INSPECT REAR BRAKE PADS AND DISCS

(a) Inspect the rear brake pads and discs.

Click here [INFO](#)

INSPECT OR CHANGE BRAKE FLUID

(a) Inspect or change the brake fluid.

Click here [INFO](#)

Fluid:

SAE J1703 or FMVSS No. 116 DOT3

SAE J1704 or FMVSS No. 116 DOT4

