

|  |                           |  |
|--|---------------------------|--|
| <b>Last Modified:</b> 12-04-2024   | 6.11:8.1.0                | <b>Doc ID:</b> RM10000002917X            |
| <b>Model Year Start:</b> 2023  | <b>Model:</b> Prius Prime | <b>Prod Date Range:</b> [12/2022 -     ] |
| <b>Title:</b> PARK ASSIST / MONITORING: PANORAMIC VIEW MONITOR SYSTEM: CUSTOMIZE PARAMETERS; 2023 - 2024 MY Prius Prius Prime [12/2022 -     ] |                           |  |

## CUSTOMIZE PARAMETERS

### CUSTOMIZE PANORAMIC VIEW MONITOR SYSTEM

(a) Customize using multi-display.

#### NOTICE:

- When the customer requests a change in a function, first make sure that the function can be customized.
- Be sure to make a note of the current settings before customizing.
- When troubleshooting a function, first make sure that the function is set to the default setting.

#### RCD

| DISPLAY | MEASUREMENT ITEM  | DEFAULT | SETTING   | ECU                |
|---------|---|---------|-----------|--------------------|
| RCD     | Switches the rear camera detection function on and off. | ON      | ON or OFF | Parking assist ECU |

