

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028PFO
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: POWER ASSIST SYSTEMS: POWER STEERING SYSTEM: DIAGNOSIS SYSTEM; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DIAGNOSIS SYSTEM

DESCRIPTION

- The power steering ECU assembly stores a DTC when it detects a malfunction in the ECU and power steering system circuit.
- GTS enables the stored DTCs to be checked and cleared, assist map to be written, and freeze framedata and Data List to be monitored.

CHECK WARNING LIGHT

(a) Turn the ignition switch to ON and check the EPS warning light.

OK:

The EPS warning light illuminates.

HINT:

If the EPS warning light does not illuminate, check the EPS warning light circuit.

Click here [INFO](#)

(b) Turn the ignition switch to ON (READY) and check the EPS warning light.

OK:

The EPS warning light turns off.

HINT:

If the EPS warning light does not illuminate, check the EPS warning light circuit.

Click here [INFO](#)

