

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000002A4CP
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> TIRE / WHEEL: TIRE AND WHEEL SYSTEM: INSPECTION; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

# INSPECTION

## PROCEDURE

### 1. INSPECT TIRES

Pre-procedure1

(a) None

Procedure1


(b) Using a dial indicator, check the runout of the tires.

**HINT:**

Measure the runout with the wheel assembly removed from the vehicle.

Maximum Tire Runout:

SPECIFIED CONDITION
1.4 mm
0.0551 in.



Post-procedure1

(c) None

