

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000002925T
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: DOOR / HATCH: BACK DOOR CLOSER ECU: INITIALIZATION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

INITIALIZATION

NOTICE:

Initialization of the multiplex network door ECU (back door initial position learning) is necessary if the following work procedures are performed while the back door is open.

- The cable to the negative (-) auxiliary battery terminal is connected.
- A power source system fuse of the power back door system is disconnected and reconnected.
- The multiplex network door ECU is replaced or the connectors are disconnected.

The power back door does not operate unless the multiplex network door ECU is initialized.

HINT:

- Initialization is not necessary if the above procedures are performed while the back door is closed.
- When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) 

(a) Initialization operation

(1) Fully close the back door by hand.

