

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000000299JO
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: DOOR LOCK: POWER DOOR LOCK CONTROL SYSTEM: PRECAUTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

PRECAUTION

PRECAUTION FOR DISCONNECTING CABLE FROM NEGATIVE (-) AUXILIARY BATTERY TERMINAL

NOTICE:

After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

Click here [INFO](#)

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

PRECAUTIONS FOR REMOVAL, INSTALLATION AND REPLACEMENT OF COMPONENTS

- (a) After replacing certain components, it may be necessary to update the ECU security key.

Click here [INFO](#)

PRECAUTIONS WHEN USING GTS

- (a) When using the GTS with the ignition switch off to troubleshoot:

Connect the GTS to the vehicle, and turn a door control switch of the multiplex network master switch assembly at intervals of 1.5 second intervals until communication between the GTS and vehicle begins.

PRECAUTION FOR REGISTRATION

- (a) Before replacing the main body ECU (multiplex network body ECU), refer to Registration.

Click here [INFO](#)

PRECAUTION WHEN REPLACING AIRBAG ECU ASSEMBLY

- (a) When the airbag ECU assembly is replaced, update the ECU security key.

Click here [INFO](#)

