


<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM1000000029X43
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> SEAT: SEAT HEATER SYSTEM: PARTS LOCATION; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

## PARTS LOCATION


### ILLUSTRATION



*A	w/ Rear Seat Heater	-	-
----	---------------------	---	---


*1	AIR CONDITIONING AMPLIFIER ASSEMBLY	*2	AIR CONDITIONING CONTROL ASSEMBLY
*3	REAR SEAT HEATER SWITCH LH	*4	REAR SEAT HEATER SWITCH RH
*5	DLC3	*6	NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK ASSEMBLY - ECU-IGP NO. 3 FUSE - S/HTR RR FUSE
*7	POWER DISTRIBUTION BOX ASSEMBLY - S/HTR F/L FUSE - S/HTR F/R FUSE	*8	NO. 2 INSTRUMENT PANEL RELAY BLOCK - S HTR RL RELAY - S HTR RR RELAY

## ILLUSTRATION



*1	FRONT SEAT CUSHION HEATER ASSEMBLY RH	*2	FRONT SEATBACK HEATER ASSEMBLY RH
*3	SEAT HEATER CONTROL SUB-ASSEMBLY RH	*4	FRONT SEAT CUSHION HEATER ASSEMBLY LH
*5	FRONT SEATBACK HEATER ASSEMBLY LH	*6	SEAT HEATER CONTROL SUB-ASSEMBLY LH

## ILLUSTRATION



*A	w/ Rear Seat Heater	-	-
*1	REAR NO. 1 SEAT CUSHION HEATER ASSEMBLY RH	*2	REAR NO. 1 SEAT CUSHION HEATER ASSEMBLY LH
*3	REAR NO. 1 SEATBACK HEATER ASSEMBLY RH	*4	REAR NO. 1 SEATBACK HEATER ASSEMBLY LH

