

| | | |
|---|---------------------------|--------------------------------------|
| Last Modified: 12-04-2024 | 6.11:8.1.0 | Doc ID: RM100000029RBZ |
| Model Year Start: 2023 | Model: Prius Prime | Prod Date Range: [12/2022 -] |
| Title: SEAT BELT: SEAT BELT WARNING SYSTEM (w/o Occupant Classification System): DIAGNOSIS SYSTEM; 2023 - 2024 MY Prius Prius Prime [12/2022 -] | | |

DIAGNOSIS SYSTEM

CHECK DLC3

(a) Check the DLC3.

Click here [INFO](#)

INSPECT AUXILIARY BATTERY VOLTAGE

(a) Measure the auxiliary battery voltage with the ignition switch off.

Standard Voltage:

11 to 14 V

If the voltage is below 11 V, recharge or replace the auxiliary battery.

