



Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029RBS
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: SEAT BELT: SEAT BELT WARNING SYSTEM (w/o Occupant Classification System): SYSTEM DIAGRAM; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

SYSTEM DIAGRAM





Communication Table

SENDER	RECEIVER	SIGNAL	COMMUNICATION METHOD
Main body ECU (multiplex network body ECU)	Combination meter assembly	<ul style="list-style-type: none"> • Front seat inner belt (front passenger seat) buckle switch • Front passenger seat occupant detection signal • Rear seat inner belt buckle switch (LH/RH/Center) • Rear door courtesy light switch signal (LH/RH) 	CAN

SENDER	RECEIVER	SIGNAL	COMMUNICATION METHOD
No. 2 skid control ECU (brake actuator assembly)	Combination meter assembly	<ul style="list-style-type: none"> • Vehicle speed • Parking brake switch 	
Hybrid vehicle control ECU	Combination meter assembly	Shift position	
Power distribution box assembly	Main body ECU (multiplex network body ECU)	<ul style="list-style-type: none"> • Front seat inner belt (front passenger seat) buckle switch • Front passenger seat occupant detection signal • Rear seat inner belt buckle switch (LH/RH/Center) 	CXPI

