


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028UXR
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: SUPPLEMENTAL RESTRAINT SYSTEMS: AIRBAG SYSTEM: CHECK MODE PROCEDURE; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

CHECK MODE PROCEDURE

CHECK MODE: DTC CHECK

(a) Select "Check Mode" and proceed with checking using the GTS.

Body Electrical > SRS Airbag > Utility



NOTICE:

Select Check Mode on the GTS to clear the DTCs.

HINT:

- DTCs can be detected more sensitively in check mode than in normal diagnosis mode.
- Perform check mode inspection when a malfunction in a squib circuit is suspected even after the normal system code is output through normal diagnosis mode inspection.

