

| | | |
|--|---------------------------|--------------------------------------|
| Last Modified: 12-04-2024 | 6.11:8.1.0 | Doc ID: RM1000000290CP |
| Model Year Start: 2023 | Model: Prius Prime | Prod Date Range: [12/2022 -] |
| Title: THEFT DETERRENT / KEYLESS ENTRY: DIGITAL KEY SYSTEM: REGISTRATION; 2023 - 2024 MY Prius Prius Prime [12/2022 -] | | |

REGISTRATION

PROCEDURE

1. CLEAR ALL DIGITAL KEYS USING MULTI-DISPLAY

NOTICE:

- Make sure to use the electrical key when turning the ignition switch to ON (IG) and clearing all the digital keys.
- If all digital keys are cleared, both the owner key and share keys are cleared.

HINT:

In this document, an electrical key refers to a registered electrical key transmitter sub-assembly.

| PROCEDURE | STEPS |
|---|--|
| 1. Start of erasure | <ol style="list-style-type: none"> 1. Turn the ignition switch to ON using electrical key. 2. Enter the following multi-display menu: Settings / Info & Security / Delete the digital keys |
| 2. Confirmation of registered electrical keys | <ol style="list-style-type: none"> 1. In accordance with the display of the multi-display, touch the electrical key to the power switch. 2. Confirm that the buzzer sounds once (short beep). |
| 3. End of erasure | <ol style="list-style-type: none"> 1. In accordance with the display of the multi-display, delete all digital keys. |

2. IMMOBILISER SYSTEM (KEY REGISTRATION)

HINT:

INFO

