

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM1000000029ZPM
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: LIGHTING (INT): GLOVE BOX LIGHT: INSPECTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

INSPECTION

PROCEDURE

1. INSPECT NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY

(a) Apply auxiliary battery voltage to the No. 1 interior illumination light assembly and check that the light illuminates.


OK:



[Click Location & Routing\(K33\).](#)

[Click Connector\(K33\).](#)

TESTER CONNECTION	SPECIFIED CONDITION
K33-2 (B) → Auxiliary battery positive (+)	Glove box light illuminates
K33-1 (L) → Auxiliary battery negative (-)	



*a	Component without harness connected (No. 1 Interior Illumination Light Assembly)
----	--

If the result is not as specified, replace the No. 1 interior illumination light assembly.

