

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM1000000029ZPC
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: LIGHTING (INT): VANITY LIGHT: INSPECTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

INSPECTION

PROCEDURE

1. INSPECT VANITY LIGHT ASSEMBLY (for LH Side)

(a) Apply auxiliary battery voltage to the vanity light assembly and check that the light illuminates.

OK:




[Click Location & Routing\(U9\)](#)

[Click Connector\(U9\)](#)

TESTER CONNECTION	SPECIFIED CONDITION
U9-4 (B) - Auxiliary battery positive (+)	Vanity light illuminates
U9-2 (E) - Auxiliary battery positive (-)	

If the result is not as specified, replace the vanity light assembly.



*a	Component without harness connected (Vanity Light Assembly)
----	---

2. INSPECT VANITY LIGHT ASSEMBLY (for RH Side)

(a) Apply auxiliary battery voltage to the vanity light assembly and check that the light illuminates.

OK:




[Click Location & Routing\(U8\)](#)

[Click Connector\(U8\)](#)

TESTER CONNECTION	SPECIFIED CONDITION
U8-4 (B) - Auxiliary battery positive (+)	Vanity light illuminates
U8-2 (E) - Auxiliary battery positive (-)	

If the result is not as specified, replace the vanity light assembly.



*a	Component without harness connected (Vanity Light Assembly)
----	---

