	ir-	
6 11 8 1 0	Doc ID: RM100000029FK4	

Prod Date Range: [12/2022 -

Title: MY SETTINGS: MY SETTINGS SYSTEM: PRECAUTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -

PRECAUTION

Last Modified: 12-04-2024

Model Year Start: 2023

PRECAUTIONS FOR DISCONNECTING CABLE FROM NEGATIVE (-) AUXILIARY BATTERY TERMINAL

Model: Prius Prime

NOTICE:

• After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

Click here NFO

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here NFO

PRECAUTION FOR REPLACING PART

(a) If any of the following procedures are performed, the settings of the My Settings System will be cleared as shown in the following table.

PART REPLACED OR PROCEDURE PERFORMED	CLEARED SETTINGS	
	ELECTRICAL KEY TRANSMITTER SUB- ASSEMBLY	BLUETOOTH DEVICE
Replace the main body ECU (multiplex network body ECU)	•	•
Replace the certification ECU (smart key ECU assembly)	•	-
Replace the radio and display receiver assembly	-	•
Erase the electrical key transmitter sub-assembly	•	-

(b) After replacing the radio and display receiver assembly, the radio and display receiver assembly may not reflect the driver settings even if the My Settings system identifies the user.

For vehicles that need an application or account for driver settings

ITEM	DESCRIPTION
Conditions	The radio and display receiver assembly is replaced when the electrical key transmitter sub-assembly is set as the My Settings device.
Symptoms	 Although an electrical key transmitter sub-assembly is set as a My Settings device, the name of the driver is blank. Even though the user is identified, the multimedia settings are not recalled.
Action	By performing the following, driver information / multimedia settings can be reflected to the vehicle. • On the screen of the multi-display, select "Settings" → "Current driver" → "Profile lock by password" to ON. (The default setting is ON.)

ITEM	DESCRIPTION
	 Switch from driver to guest. Switch to the original driver again. Enter the password.
	NOTICE: By following the procedure, the assigned settings of the My Settings device (electrical key transmitter sub-assembly) will be cleared.

For vehicles that do not need an application or account for driver settings

ITEM	DESCRIPTION	
Conditions	The radio and display receiver assembly is replaced when the electrical key transmitter sub-assembly is set as the My Settings device.	
Symptoms	Although an electrical key transmitter sub-assembly is set as a My Settings device, the name of the driver is blank.	
Action	Method of action before replacing the radio and display receiver assembly	
	1. On the screen of the multi-display, select "Settings" \to "Info & Security" \to "System reset" and perform an initialization.	
	Method of action after replacing the radio and display receiver assembly	
	 On the screen of the multi-display, register Driver 1 / Driver 2 / Driver 3. On the screen of the multi-display, select "Settings" → "Info & Security" → "System reset" and perform an initialization. 	
	NOTICE: By following the procedure, the assigned settings of the My Settings device (electrical key transmitter sub-assembly) will be cleared.	

PRECAUTION FOR REGISTRATION

(a) Before replacing the main body ECU (multiplex network body ECU), Registration.







