

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000000289ND
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: ADVANCED DRIVER ASSISTANCE SYSTEM: FRONT SIDE RADAR SENSOR SYSTEM: C1A1804; Front Side Radar Sensor (Module "B") System Internal Failure; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DTC	C1A1804	Front Side Radar Sensor (Module "B") System Internal Failure
------------	----------------	---

DESCRIPTION

This DTC is stored when the front side radar sensor (B) detects an internal malfunction.

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	DTC OUTPUT FROM	PRIORITY
C1A1804	Front Side Radar Sensor (Module "B") System Internal Failure	A front side radar sensor (B) internal malfunction is detected.	Front side radar sensor (B)	Front Side Radar "B"	A

CAUTION / NOTICE / HINT

NOTICE:

- When checking for DTCs, make sure that the pre-collision system is turned on.
- After replacing the front side radar sensor, make sure to perform ECU writing.

Click here [INFO](#)

- After replacing the front side radar sensor, make sure to perform front side radar sensor beam axis alignment and clear all stored vehicle control history of each system.

HINT:

Front side radar sensor beam axis alignment can be performed by using "Triangle Target", "Driving Adjustment" or "ECU DATA SAVE/WRITE".

Triangle Target: [INFO](#)

Driving Adjustment: [INFO](#)

ECU DATA SAVE/WRITE: [INFO](#)

PROCEDURE

1.	REPLACE FRONT SIDE RADAR SENSOR (B)
-----------	--

HINT:

Click here [INFO](#)

NEXT ► **END**

