

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000028U0N
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> CELLULAR COMMUNICATION: SAFETY CONNECT SYSTEM: CUSTOMIZE PARAMETERS; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

## CUSTOMIZE PARAMETERS

### CUSTOMIZE TELEMATICS SYSTEM

(a) Customizing with the GTS.

**NOTICE:**

- When the customer requests a change in a function, first make sure that the function can be customized.
- Be sure to make a note of the current settings before customizing.
- When troubleshooting a function, first make sure that the function is set to the default setting.
- When adjusting the telematics microphone volume, please verify sound volume with the call before taking the vehicle back to customer.

(1) Enter the following menus: Customize Setting / Others.

(2) Select the setting by referring to the table below.

**Others**

TESTER DISPLAY	DESCRIPTION	DEFAULT	SETTING	ECU
Telematics Microphone Volume Adjust	Sets the telephone microphone assembly volume	6	\$01:1(MIN),\$02:2,\$03:3,\$04:4,\$05:5,\$06:6,\$07:7,\$08:8,\$09:9,\$0A:10,\$0B:11(MAX)	DCM (telematics transceiver)
Telematics Speaker Volume Adjust	Sets the speaker volume	8	\$01:1(MIN),\$02:2,\$03:3,\$04:4,\$05:5,\$06:6,\$07:7,\$08:8,\$09:9,\$0A:10,\$0B:11,\$0C:12,\$0D:13,\$0E:14(MAX)	DCM (telematics transceiver)

