

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000028TZQ
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> GARAGE DOOR OPENER: GARAGE DOOR OPENER SYSTEM (for Digital Inner Mirror): DATA LIST / ACTIVE TEST; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

## DATA LIST / ACTIVE TEST

### DATA LIST

#### NOTICE:

In the table below, the values listed under "Normal Condition" are reference values. Do not depend solely on these reference values when deciding whether a part is faulty or not.

#### HINT:

Using the GTS to read the Data List allows the values or states of switches, sensors, actuators and other items to be read without removing any parts. This non-intrusive inspection can be very useful because intermittent conditions or signals may be discovered before parts or wiring is disturbed. Reading the Data List information early in troubleshooting is one way to save diagnostic time.

(a) Enter the following menus: Body Electrical / Digital Rear-View Mirror / Data List.

(b) Read the Data List according to the display on the GTS.

#### Body Electrical > Digital Rear-View Mirror > Data List

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Total Distance Traveled	Current total driving distance	0 to 999999	Equivalent to the actual total driving distance	-
Total Distance Traveled - Unit	Unit of total distance traveled	km or mile	-	-

