

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029DUO
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: PARK ASSIST / MONITORING: BLIND SPOT MONITOR SYSTEM: DIAGNOSIS SYSTEM; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DIAGNOSIS SYSTEM

DESCRIPTION

- (a) Blind spot monitor data and Diagnostic Trouble Codes (DTCs) can be read from the Data Link Connector 3 (DLC3) of the vehicle. When the system seems to be malfunctioning, use the GTS to check for malfunctions and to perform repairs.

CHECK DLC3

- (a) Check the DLC3.

Click here [INFO](#)

DIAGNOSIS FUNCTION

- (a) When the system is malfunctioning or is temporarily unavailable and cannot be used, a notification is displayed on the multi-information display to notify the driver.
- "[Blind Spot Monitor System icon] System Malfunction Visit Your Dealer" is displayed on the multi-information display
 - "[Blind Spot Monitor System icon] System Stopped See Owner's Manual" is displayed on the multi-information display
 - "[Rear Cross Traffic Alert Buzzer System icon] System Malfunction Visit Your Dealer" is displayed on the multi-information display
 - "[Rear Cross Traffic Alert Buzzer System icon] System Stopped See Owner's Manual" is displayed on the multi-information display
 - "[Safe Exit Assist System icon] System Malfunction Visit Your Dealer" is displayed on the multi-information display
 - "[Safe Exit Assist System icon] System Stopped See Owner's Manual" is displayed on the multi-information display

