

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM1000000028V00
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: PARK ASSIST / MONITORING: PARKING ASSIST ECU: REMOVAL; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

REMOVAL

CAUTION / NOTICE / HINT


The necessary procedures (adjustment, calibration, initialization or registration) that must be performed after parts are removed and installed, or replaced during parking assist ECU removal/installation are shown below.

Necessary Procedures After Parts Removed/Installed/Replaced

REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURES	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURES ARE NOT PERFORMED	LINK
Parking assist ECU	Parking assist ECU initialization	Parking Support Brake System	INFO
		Panoramic View Monitor System	INFO
		Advanced Park	INFO
	Camera cleaner setting operation*1	Multimedia switch is not displayed	INFO
w/ Occupant Classification System: Front passenger seat*	Zero point calibration (Occupant classification system)	<ul style="list-style-type: none"> • Occupant Classification System • Passenger airbag ON/OFF indicator • Airbag System (Front passenger side) • Seat Belt Warning System (Front passenger) 	INFO
*1: w/ Rear Camera Cleaner System			

CAUTION / NOTICE / HINT

COMPONENTS (REMOVAL)



	PROCEDURE	PART NAME CODE			
1	PRECAUTION	-		-	-
2	FRONT SEAT ASSEMBLY RH	-	-	-	-
3	PARKING ASSIST ECU COVER	86796	-	-	-
4	PARKING ASSIST ECU WITH BRACKET	-	-	-	-
5	NO. 1 PARKING ASSIST ECU BRACKET	86791C	-	-	-

*1	PARKING ASSIST ECU	-	-
----	--------------------	---	---

PROCEDURE

1. PRECAUTION



Click here [INFO](#)

2. REMOVE FRONT SEAT ASSEMBLY RH

(a) Use the same procedure as for the LH side.


(1) for Manual Seat:

Click here [INFO](#)


(2) for Power Seat:

Click here [INFO](#)


3. REMOVE PARKING ASSIST ECU COVER



4. REMOVE PARKING ASSIST ECU WITH BRACKET



5. REMOVE NO. 1 PARKING ASSIST ECU BRACKET



P

