



Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000002B4GQ
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: M20A-FXS (FUEL): FUEL SYSTEM: SYSTEM DIAGRAM; 2023 - 2024 MY Prius Prius Prime [03/2023 -]		

SYSTEM DIAGRAM



*A	for HEV Model	-	-
*1	ECM	*2	Fuel Pressure Sensor (for High Pressure)
*3	Fuel Delivery Pipe (for High Pressure)	*4	Direct Fuel Injector Assembly
*5	No. 2 Fuel Pressure Sensor (for Low Pressure)	*6	Fuel Delivery Pipe Sub-assembly (for Low Pressure)
*7	Port Fuel Injector Assembly	*8	Fuel Pump Control ECU

*9	Fuel Tank Sub-Assembly	*10	Fuel Main Valve Assembly
*11	Fuel Filter	*12	Fuel Pump (for Low Pressure)
*13	Fuel (Engine Room Side) Pump Assembly (for High Pressure)	*14	Fuel SUS Filter
*15	Fuel Pressure Pulsation Damper	*16	Spill Control Valve
*17	Check Valve	*18	Fuel Relief Valve
*19	Camshaft (Cam to Drive Fuel Pump)	-	-



*A	for PHEV Model	-	-
*1	ECM	*2	Fuel Pressure Sensor (for High Pressure)
*3	Fuel Delivery Pipe (for High Pressure)	*4	Direct Fuel Injector Assembly
*5	No. 2 Fuel Pressure Sensor (for Low Pressure)	*6	Fuel Delivery Pipe Sub-assembly (for Low Pressure)

*7	Port Fuel Injector Assembly	*8	Fuel Pump Control ECU
*9	Fuel Tank Sub-Assembly	*10	No. 2 Fuel Main Valve Assembly
*11	Fuel Main Valve Assembly	*12	Fuel Pump with Filter Assembly (for Low Pressure)
*13	Fuel Filter	*14	Fuel (Engine Room Side) Pump Assembly (for High Pressure)
*15	Fuel SUS Filter	*16	Fuel Pressure Pulsation Damper
*17	Spill Control Valve	*18	Check Valve
*19	Fuel Relief Valve	*20	Camshaft (Cam to Drive Fuel Pump)

