

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002923S
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: DOOR / HATCH: POWER BACK DOOR SYSTEM: VEHICLE CONTROL HISTORY (RoB); 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

VEHICLE CONTROL HISTORY (RoB)

NOTICE:

- If the vehicle or vehicle controls are operated (for example, during initial inspection when the vehicle is brought in for repair) before vehicle control history (RoB) has been read out and saved, the vehicle control history (RoB) information could be lost.
- The function "Read vehicle control history (RoB)" uses the current system time setting inside the GTS and the time counter inside the controlling ECU to calculate the timings shown in the vehicle control history (RoB). For this reason, before reading out the vehicle control history (RoB), first make sure that the GTS system clock is accurately set to the current time.
- The time counter in the control ECU may deviate by up to +/- 10% due to the characteristics of the time counter.
- The time counter in the control ECU is reset approximately 34 days before the "Current" value due to the characteristics of the time counter. Therefore, the time information stored before the 34th day may not be accurately displayed.

VEHICLE CONTROL HISTORY (RoB)

(a) Check vehicle control history (RoB) according to the display on the GTS.

Body Electrical > Back Door > Utility

TESTER DISPLAY
Vehicle Control History (RoB)

ROB CODE	ROB ITEM	ITEM DESCRIPTION
X283E	Back Door Operation History	Memorize the factors when the power back door operated
X2903	Back Door Non-Operation History	Memorize the factors when the power back door non-operation

Body Electrical > Main Body > Utility

TESTER DISPLAY
Vehicle Control History (RoB)

ROB CODE	ROB ITEM	ITEM DESCRIPTION
X2303	Trunk/Back Door	Memorize the factors when the power back door operated

HINT:

Vehicle Control History (RoB): The main body ECU (multiplex network body ECU) records the power back door system vehicle control history (RoB), which can be read out using the GTS.

CLEAR VEHICLE CONTROL HISTORY (RoB)

NOTICE:

Performing following procedure will delete all vehicle control history (RoB) records.

(a) Clear vehicle control history (RoB) according to the display on the GTS.

Body Electrical > Back Door > Utility

TESTER DISPLAY
Vehicle Control History (RoB)

Body Electrical > Main Body > Utility

TESTER DISPLAY
Vehicle Control History (RoB)

