

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM1000000029QFD
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> EXTERIOR PANELS / TRIM: QUARTER GARNISH: REMOVAL; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

## REMOVAL


### CAUTION / NOTICE / HINT

**HINT:**

- Use the same procedure for the RH side and LH side.
- The following procedure is for the LH side.

### CAUTION / NOTICE / HINT


#### COMPONENTS (REMOVAL)




	PROCEDURE	PART NAME CODE			
1	QUARTER PILLAR COVER SUB-ASSEMBLY	62506C	INFO	-	-
2	DOOR TRIM RETAINER CAP	-	-	-	-

## PROCEDURE

### 1. REMOVE QUARTER PILLAR COVER SUB-ASSEMBLY



	Remove in this Direction	-	-
---	--------------------------	---	---

- (1) Apply protective tape around the quarter pillar cover sub-assembly as shown in the illustration.
- (2) Disengage the 2 clips and pin to remove the quarter pillar cover sub-assembly as shown in the illustration.

**2. REMOVE DOOR TRIM RETAINER CAP**

(a) When reusing the quarter pillar cover sub-assembly:

