

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000000292K5
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> LIGHTING (EXT): SIDE TURN SIGNAL LIGHT ASSEMBLY: REMOVAL; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

## REMOVAL


### CAUTION / NOTICE / HINT

**HINT:**

- Use the same procedure for the RH side and LH side.
- The following procedure is for the LH side.

### CAUTION / NOTICE / HINT


#### COMPONENTS (REMOVAL)



	PROCEDURE	PART NAME CODE			
1	OUTER MIRROR	87961	<a href="#">INFO</a>	-	-
2	OUTER MIRROR COVER	87945	-	-	-
3	NO. 3 OUTER MIRROR COVER	8794BA	<a href="#">INFO</a>	-	-
4	SIDE TURN SIGNAL LIGHT ASSEMBLY	81740	-	-	-

## PROCEDURE


### 1. REMOVE OUTER MIRROR

	Click here <a href="#">INFO</a>
---	---------------------------------

### 2. REMOVE OUTER MIRROR COVER

Click here [INFO](#)

### 3. REMOVE NO. 3 OUTER MIRROR COVER

	w/o Panoramic View Monitor System: Click here <a href="#">INFO</a> w/ Panoramic View Monitor System: Click here <a href="#">INFO</a>
---	---

### 4. REMOVE SIDE TURN SIGNAL LIGHT ASSEMBLY

