

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002AXF7
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: HEATING / AIR CONDITIONING: HEAT EXCHANGER TEMPERATURE SENSOR: REMOVAL; 2023 - 2024 MY Prius Prius Prime [03/2023 -]		

REMOVAL

CAUTION / NOTICE / HINT


The necessary procedures (adjustment, calibration, initialization or registration) that must be performed after parts are removed and installed, or replaced during thermostat assembly removal/installation are shown below.




Necessary Procedures After Parts Removed/Installed/Replaced

REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURES	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURES ARE NOT PERFORMED	LINK
Front bumper assembly*	Front television camera view adjustment	Panoramic View Monitor System	INFO
		Advanced Park	INFO
*: Even when not replacing the part, it is necessary to perform the specified necessary procedures after installation.			

CAUTION / NOTICE / HINT

COMPONENTS (REMOVAL)



PROCEDURE		PART NAME CODE			
1	FRONT BUMPER ASSEMBLY	-	-	-	-
2	NO. 1 COOLER PACKING	88578Z	-	-	-
3	NO. 1 AIR CONDITIONING THERMISTOR ASSEMBLY	88620Q	-	-	-


*1	NO. 1 PIPING CLAMP	-	-
•	Non-reusable part	-	-

PROCEDURE

1. REMOVE FRONT BUMPER ASSEMBLY

Click here [INFO](#)

2. REMOVE NO. 1 COOLER PACKING



3. REMOVE NO. 1 AIR CONDITIONING THERMISTOR ASSEMBLY

