

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002A2JQ
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: POWER OUTLETS (INT): WIRELESS CHARGING SYSTEM: PRECAUTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

PRECAUTION

PRECAUTION FOR WHEN USING WIRELESS CHARGER

- (a) As the wireless charger is a device for charging smartphones, do not charge anything other than a smartphone.
- (b) When charging a smartphone while driving, for safety reasons, the driver should not operate the smartphone.
- (c) People with implantable cardiac pacemakers, cardiac resynchronization therapy pacemakers or implantable cardioverter defibrillators, or any other electrical medical device, should consult their physician about usage of the wireless charging system. Operation of the wireless charging system may have an affect on medical devices.
- (d) If the following precautions are not observed, a fire, equipment failure or damage, or burns due to overheating may occur:
- Do not put any metallic objects between the charging area and the smartphone while charging.
 - Do not attach metallic objects, such as aluminum stickers, to the charging area, the smartphone or its case.
 - Do not cover the smartphone with a cloth or other object while charging.
 - Do not attempt to charge any device that is not a specified smartphone.
 - Do not disassemble, modify or remove the mobile wireless charger cradle assembly.
 - Do not subject the mobile wireless charger cradle assembly to excessive force or impact.
- (e) In the following situations, the wireless charging system may not operate correctly:
- When the smartphone is fully charged.
 - When a small object or cushion material with a thickness of 2 mm (0.079 in.) or more is in between the charging area and the smartphone.
 - When a non-Qi-compatible cover or accessory is attached to the smartphone.
 - When a case with a thickness of 2 mm (0.079 in.) or more or non-Qi-compatible cover or accessory is attached to the smartphone.
 - When there is a decoration in the charging area or smartphone.
 - When a metal plate or magnetic case is used in the charging area.
 - When a case with a cushion material, etc. that increases its thickness is used in the charging area.
 - When a smartphone that has a case with a ring installed is used.
 - When the temperature around the charging tray is 35 °C (95 °F) or more due to insolation, etc.
 - When a smartphone is not placed correctly on the charging area.
 - When a smartphone is not centered on the charging area.
 - When in an area with strong radio waves, noise, etc.
 - When the smartphone is in contact with, or is covered by a metallic object.
 - When an RF remote controller is being used nearby.
- (f) Do not bring magnetic cards, such as electronic toll collection cards or contactless IC cards, or magnetic recording media close to the charging area while charging. Otherwise, data may be erased. Additionally, do not bring precision instruments, such as wrist watches, close to the mobile wireless charger cradle assembly, as such objects may malfunction.
- (g) To prevent the auxiliary battery from discharging, do not use the wireless charging system for a long period of time with the ignition switch in a state other than ON (READY).

