



FUEL INJECTOR

COMPONENTS



FU

FU



[N*m (kgf*cm, ft.*lbf)] : Specified torque

● Non-reusable part