

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM1000000029I67
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> SEAT BELT: SEAT BELT WARNING SYSTEM (w/ Occupant Classification System): PARTS LOCATION; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		


## PARTS LOCATION

## ILLUSTRATION



*1	NO. 2 SKID CONTROL ECU (BRAKE ACTUATOR ASSEMBLY)	-	-
----	--------------------------------------------------	---	---


## ILLUSTRATION



H

*1	MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)	*2	POWER DISTRIBUTION BOX ASSEMBLY
*3	HYBRID VEHICLE CONTROL ECU	*4	COMBINATION METER ASSEMBLY - SEAT BELT WARNING BUZZER
*5	FRONT SEAT BELT WARNING LIGHT	*6	REAR SEAT BELT WARNING LIGHT
*7	AIRBAG ECU ASSEMBLY	*8	DLC3


## **ILLUSTRATION**



H

*1	FRONT SEAT INNER BELT ASSEMBLY LH	*2	FRONT SEAT INNER BELT ASSEMBLY RH
*3	FRONT SEAT ADJUSTER ASSEMBLY RH - FRONT OCCUPANT CLASSIFICATION SENSOR LH - REAR OCCUPANT CLASSIFICATION SENSOR LH	-	-

**ILLUSTRATION**



H

*1	REAR DOOR LOCK WITH MOTOR ASSEMBLY RH - DOOR COURTESY SWITCH	*2	REAR DOOR LOCK WITH MOTOR ASSEMBLY LH - DOOR COURTESY SWITCH
*3	REAR SEAT INNER BELT ASSEMBLY RH	*4	REAR SEAT INNER WITH CENTER BELT ASSEMBLY LH

