


Paint Basic

1. Paint Separation



Paint and pigment separate into two parts during storage, resulting in a clear portion of paint in the upper part of the can.

CAUSES:

- Prolonged storage in excessive temperatures.
- Low paint viscosity.
- Paint accidentally mixed with a different paint type.

PREVENTION:

- Store the paint in a dark, cool place, 68 °F (20 °C) or below. If it is stored for a prolonged period, invert the can occasionally.
- Do not return paint diluted with reducer/thinner to the original can.

CORRECTIVE ACTIONS:

Stir up the paint thoroughly before reuse.