


2006 Honda Insight

2000-06 ELECTRICAL Relay And Control Unit Locations - Insight

2000-06 ELECTRICAL

Relay And Control Unit Locations - Insight

ENGINE COMPARTMENT




G03682863

Fig. 1: Identifying Engine Compartment Relay And Control Unit Locations

Courtesy of AMERICAN HONDA MOTOR CO., INC.

DASHBOARD




G03682864

Fig. 2: Identifying Dashboard Relay And Control Unit Locations (1 Of 2)
Courtesy of AMERICAN HONDA MOTOR CO., INC.

2006 Honda Insight

2000-06 ELECTRICAL Relay And Control Unit Locations - Insight




G03682865

Fig. 3: Identifying Dashboard Relay And Control Unit Locations (2 Of 2)
Courtesy of AMERICAN HONDA MOTOR CO., INC.

FLOOR AND REAR

2006 Honda Insight

2000-06 ELECTRICAL Relay And Control Unit Locations - Insight



G03682866

Fig. 4: Identifying Floor And Rear Relay And Control Unit Locations
Courtesy of AMERICAN HONDA MOTOR CO., INC.