Power Distribution

– Under-hood Fuse/Relay Box – Fuse 16



©2006 American Honda Motor Co., Inc.