

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000028X3T
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> BRAKE CONTROL / DYNAMIC CONTROL SYSTEMS: ELECTRONICALLY CONTROLLED BRAKE SYSTEM: C11001C; Brake Pedal Position Sensor "A" Supply Voltage Circuit Voltage Out of Range; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

<b>DTC</b>	<b>C11001C</b>	<b>Brake Pedal Position Sensor "A" Supply Voltage Circuit Voltage Out of Range</b>
------------	----------------	--

## DESCRIPTION

Refer to DTC C110000.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	DTC OUTPUT FROM	PRIORITY	NOTE
C11001C	Brake Pedal Position Sensor "A" Supply Voltage Circuit Voltage Out of Range	The sensor supply voltage (VCSK) is 4.7 V or less, or 5.3 V or more for 0.2 seconds or more.	<ul style="list-style-type: none"> <li>Wire harness and connector</li> <li>Brake pedal stroke sensor assembly</li> <li>No. 1 skid control ECU (brake booster with master cylinder assembly)</li> </ul>	Comes on	Brake/EPB	A	<ul style="list-style-type: none"> <li>SAE Code: C1100 (Case 1)</li> <li>Output ECU: Both skid control ECUs</li> </ul>

## MONITOR DESCRIPTION

The No. 2 skid control ECU (brake actuator assembly) monitors the power supply voltage of the brake pedal stroke sensor assembly. When the brake pedal stroke sensor assembly power supply voltage is outside of the normal range, the No. 2 skid control ECU (brake actuator assembly) judges that the power supply is abnormal and illuminates the MIL and stores this DTC.

## MONITOR STRATEGY

Related DTCs	C1100 (Case 1): Brake pedal position sensor voltage circuit/open
Required Sensors/Components(Main)	No. 2 skid control ECU (brake actuator assembly)
Required Sensors/Components(Related)	No. 2 skid control ECU (brake actuator assembly)
Frequency of Operation	Continuous
Duration	0.198 seconds

MIL Operation	Immediately
Sequence of Operation	None

## TYPICAL ENABLING CONDITIONS

Monitor runs whenever the following DTCs are not stored	None
Both of the following conditions are met	A and B
A. Both of the following conditions are met	More than 0.198 seconds
+BS cut MOS	Valid
+BS cut MOS voltage	Higher than 7.4 V
B. VCSK	Valid
+BS cut MOS voltage	Higher than 7.8 V

## TYPICAL MALFUNCTION THRESHOLDS

Brake pedal position sensor power supply	Below 4.8 V, or higher than 5.2 V
--	-----------------------------------

## COMPONENT OPERATING RANGE

Both of the following conditions are met	A and B
A. Both of the following conditions are met	More than 0.198 seconds
+BS cut MOS	Valid
+BS cut MOS voltage	Higher than 7.4 V
B. VCSK	Valid
Brake pedal position sensor1 power supply	4.8 V or higher, and 5.2 V or less

## CONFIRMATION DRIVING PATTERN

### NOTICE:

When performing the normal judgment procedure, make sure that the driver door is closed and is not opened at any time during the procedure.

### HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.
- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

- Connect the GTS to the DLC3.
- Turn the ignition switch to ON and turn the GTS on.
- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Turn the ignition switch off.
- Turn the ignition switch to ON (READY) and turn the GTS on.
- Wait for 1 second or more. [\*]

### HINT:

[\*]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

7. Enter the following menus: Chassis / Brake/EPB\* / Utility / All Readiness.

\*: Electric Parking Brake System

8. Check the DTC judgment result.

**HINT:**

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE, perform driving pattern again.

## WIRING DIAGRAM

Refer to DTC C110000.

Click here [INFO](#)

## CAUTION / NOTICE / HINT

**NOTICE:**

Make sure to wait 5 minutes or more with the ignition switch turned off before removing the integration control supply or disconnecting any supply power circuit from the integration control supply, in order for the voltage to be discharged and self-diagnosis to run.

## PROCEDURE

<b>1.</b>	<b>CHECK BRAKE PEDAL</b>
-----------	--------------------------

- (a) Check that the brake pedal and the brake pedal stroke sensor assembly are properly installed and that the pedal can be depressed normally.
- (b) Check and adjust the brake pedal height.

**HINT:**

Click here [INFO](#)

- (c) Adjust the brake pedal stroke sensor assembly.

**HINT:**

Click here [INFO](#)

## **NEXT**



<b>2.</b>	<b>CHECK HARNESS AND CONNECTOR (BRAKE BOOSTER WITH MASTER CYLINDER ASSEMBLY - BRAKE PEDAL STROKE SENSOR ASSEMBLY)</b>
-----------	---

Pre-procedure1

- (a) Turn the ignition switch off.

## Procedure1

(b) Make sure that there is no looseness at the locking part and the connecting part of the connectors.

OK:

The connector is securely connected.

## Pre-procedure2

(c) Disconnect the A3 No. 1 skid control ECU (brake booster with master cylinder assembly) connector.

(d) Disconnect the A5 brake pedal stroke sensor assembly connector.

## Procedure2

(e) Check both the connector case and the terminals for deformation and corrosion.

OK:

No deformation or corrosion.

## Procedure3

(f) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A3,A5\).](#)

[Click Connector\(A3\).](#)

[Click Connector\(A5\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
A3-27 (SKG1) - A5-5 (SKG)	Always	Below 1 $\Omega$	$\Omega$
A3-27 (SKG1) or A5-5 (SKG) - Body ground	Always	10 k $\Omega$ or higher	k $\Omega$
A3-28 (VSK1) - A5-4 (VCSK)	Always	Below 1 $\Omega$	$\Omega$
A3-28 (VSK1) or A5-4 (VCSK) - Body ground	Always	10 k $\Omega$ or higher	k $\Omega$

## Post-procedure1

(g) None

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**



**3. INSPECT BRAKE BOOSTER WITH MASTER CYLINDER ASSEMBLY (SENSOR OUTPUT)**

## Pre-procedure1

(a) Reconnect the A3 No. 1 skid control ECU (brake booster with master cylinder assembly) connector.

(b) Turn the ignition switch to ON.

Procedure1

(c) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A5\).](#)

[Click Connector\(A5\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
A5-4 (VCSK) - A5-5 (SKG)	Ignition switch ON	4.84 to 5.16 V	V

Post-procedure1

(d) None

**OK** ► REPLACE BRAKE PEDAL STROKE SENSOR ASSEMBLY

Click here [INFO](#)

**NG** ► REPLACE BRAKE BOOSTER WITH MASTER CYLINDER ASSEMBLY

Click here [INFO](#)

